

VQM-1000BLU Firmware Update Instructions



Attention:

Please read instructions carefully. Failure to follow instructions may cause un-repairable damage to your unit.



Attention:

Firmware updates should only be downloaded directly from www.VisionQuestCE.com
Do not attempt to install firmware obtained from other sources.

Introduction

This document describes the software (firmware) updating procedure for VQM-1000BLU, please follow the instructions included. If you encounter any problems during the software update procedure do not power off the unit, please contact VisionQuest Consumer Electronics.

Downloading updates

Download the latest firmware updates from www.VisionQuestCE.com - Navigate to the product page of your player and if downloads are available for that product they will be listed on the "Downloads" link. If a firmware update is available right click on the download link and click "Save as". Save the file to a location on your computer. Ensure you download firmware for your model. Your model number should appear in the filename.

Burning update

Firmware update must be burned to a blank CD-R or CD-RW. It is recommended to set your software to verify disc after burning. Firmware download must be burned as an ISO Disc. Burning the file directly to the CD will not work.

With Nero Burning ROM

1. Right click on the file downloaded. Select "Open With" -> "Nero Burning ROM"
2. Insert a blank CD-R or CD-RW into your CD Burning Drive
3. If you have never burned a CD previously, please check the "Determine Maximum Speed" box
4. Check the "Write" box as well as the "Finalize CD" check boxes.
5. Check the "Buffer underrun protection box.
6. Click Burn
7. When the writing to disc screen comes up, we suggest to check the "Verify written data" option.
7. Wait for disc to burn

With other CD Burning software

The method to burn an ISO image should be similar with other software. Ensure that you choose the option to burn an ISO image, and that you are not just burning the file to a blank CD.

Updating Unit



Attention:

Do not power off unit while firmware is being updated.
Do not interrupt power while firmware is being updated.



Attention:

Do not open/close drive while firmware is being updated.
Ensure disc is dirt and scratch free.

1. Power on unit and insert disc with firmware update on it.
2. Wait for firmware information screen to be loaded.
3. Follow on screen instructions to update firmware.
4. Unit will reboot when firmware is updated.